



New Zealand Ph. 03 379 7370. Fax 03 379 7371. Mobile 021 637 656
P. O. Box 33321 Christchurch 8044. 11 Henry Street, Waltham, Christchurch

pearsons.co.nz

earlyfordparts@xtra.co.nz

Right hand Drive Parts List.

A Comprehensive listing of original and reproduction parts.

Please note: Not all parts are manufactured. Not all parts can be guaranteed to be stocked at any one time.

- #Front floor mat. Original Spatter Pattern.
- #Pedal mat.
- #Clutch pedal.
- #Brake pedal.
- #Bellhousing for 1928 multi-plate clutch.
- #Bellhousing for 1930 single plate clutch.
- #Pedal shaft from bellhousing.
- #Shaft collar.
- #Floor board sets 'AR'.
- #Floor board sets 1928/29.
- #Floor board sets 1930.
- #Inlet manifold.
- #Steering box 7 tooth. (Inc. all parts associated with the steering box.)
- #Steering box 2 tooth. (Inc. all parts associated with the steering box.)
- #Drag link.
- #Right hand steering ball joints.
- #Left hand steering ball joint.
- #Drop arm from steering box.
- Gearbox top 1928. 'AR'.
- #Gearbox top 1928.
- #Gearbox top 1930
- #Gearlever 1928/29.
- #Gearlever 1930.
- #Stop light switch 1928/29.
- #Right hand tail light bracket 28/29. Cast.
- #Right hand tail light bracket 1930. Pressed.
- #Mark 1 Aircleaner.
- #Mark 2 Aircleaner.
- #Throttle and advance and control rods.
- #Accelerator mechanism arms, clamp to steering column.
- #Loom 2 bulb
- #Loom 1 bulb.
- #Fuel tank 1928/29.
- #Fuel tank 1930. For early dash.
- #Fuel tank 1930. For later dash.
- #Robertson screws used throughout most vehicles.
- #Brake equalizer bar 1929/1930.
- #Starter motor switch activating arm. (Bolts to back of block.)
- #Exhaust manifold clamp. Special clamp made for right hand drive. Made in New Zealand.
- #Gear lever plate 1930.
- #Gear knob. (different shape).
- # Rear vision mirror.

Prices upon application.

